

Millad® NX® 8000 ECO delivers crystal clear clarity in polypropylene (PP), while extending sustainability benefits in the production of clarified PP parts, by offering faster production rates and average energy savings of 10% compared to conventional clarifiers.

Millad® NX® 8000 ECO allows converters to process PP at significantly lower temperatures up to 40°C less than traditional clarifiers – while yielding similar or even better optical properties. These cooler temperatures reduce energy demands and associated carbon dioxide (CO₂) emissions, enabling more sustainable solutions.

Brand owners using the Millad NX 8000 ECO clarified resin can display a UL Environmental Claim Validation (ECV) label on their injection molded packaging to illustrate their dedication to sustainability.






REDUCE YOUR

CARBON

FOOTPRINT



It's important to run your own trials, to measure the aesthetic results and actual energy savings realized in your own plant. Milliken is here to help you do just that remotely and efficiently.



Before the Trial



Milliken needs to understand how you run PP resins. Therefore, it's important to share information.

Please complete this table with the settings of the reference resin before the trial and share with the Milliken team.

Part Description	
Machine	Hydraulic/Electric/Hybrid
Reference resin	
Millad NX 8000 ECO resin	
Shot weight (g)	
Part weight (g)	

	Settings Reference Resin
IM Temperature ¹ (°C)	
Cycle Time (sec)	
Injection Time ² (sec)	
Charging Time ³ (sec)	
Cooling Time (sec)	

¹Injection Moulding Temperature = Max. Peak Barrel Temperature ²Injection Time = Filling Time ³Charging Time = Plastification Time = Dosing Time

During the Trial



- **1. Run the reference resin at standard settings.**Collect 5-10 samples from the same mold cavities in each batch, and label them for lab analysis.
- 2. Thoroughly purge the resin from the injection molding machine.
- 3. Run the Millad NX 8000 ECO resin at standard settings.

Collect 5-10 samples from the same mold cavities in each batch, and label them for lab analysis.

4. Next, optimize the processing temperature by

- reducing the barrel temperature in incremental steps until the molded part is no longer acceptable or the measured resin melt temperature does not continue to decrease.
- 5. Finally, optimize the cycle time, reducing the cooling time in increments until the molded part is no longer acceptable.

Collect 5-10 samples from the same mold cavities in each batch, and label them for lab analysis.

6. Complete the settings of the Millad NX 8000 ECO resin.

	Settings Millad NX 8000 ECO Resin
IM Temperature ¹ (°C)	
Cycle Time (sec)	
Injection Time ² (sec)	
Charging Time ³ (sec)	
Cooling Time (sec)	

¹Injection Moulding Temperature = Max. Peak Barrel Temperature ²Injection Time = Filling Time

³Charging Time = Plastification Time = Dosing Time

After the Trial



- 1. Ship the collected and labeled samples to the Milliken facility.
- 2. The experts in Milliken's lab will conduct a part analysis.
- 3. The Milliken team will prepare a full trial report including energy consumption and cycle times for both resins, energy savings and cost savings realized, and the amount of CO₂ reduced.



Example Trial Report




After running the trial at your plant, the Milliken team will prepare a full trial report including:

- Energy consumption for both resins
- Cycle time for both resins
- Energy savings
- CO2 reduction
- Haze reduction
- Cost savings



Calculate your energy savings using our web application: millad.milliken.com



It's that easy. Don't let today's current logistical challenges prevent you from realizing vital savings when molding your PP parts. Contact Milliken today, and let us get you on the path to saving money and energy with Millad NX 8000 ECO - clarified PP resin.

THE ULTRACLEAR WAY TO GO CIRCULAR with Millad® NX® 8000 ECO



Milliken

chemical.milliken.com

© Copyright 2021 Milliken & Company. All rights reserved. Milliken , Millad , and NX are registered trademarks of Milliken & Company. 03.25.2021

NORTH AMERICA

Spartanburg, SC, USA Tel: 800-910-5592 Fax: 864-503-2430 millichem@milliken.com

ASIA

Singapore Tel: 65-6377-0770 Fax: 65-6377-0990 asiachem@milliken.com

EUROPE

Gent, Belgium Tel: 32-9-265-1100 Fax: 32-9-265-1195 eurochem@milliken.com

ASIA

Shanghai Tel: 86-21 6145-5555 Fax: 86-21 6145-5558 asiachem@milliken.com

LATIN AMERICA

Sao Paulo, Brazil Tel: 55-11-3043-7942 Fax: 55-11-3043-7096 lachem@milliken.com

ASIA

Pune, India Tel: (20) 4011-0601 Fax: (20) 4011-0602 asiachem@milliken.com

LATIN AMERICA

Mexico City, Mexico Tel: 52-55-3088 3600 Fax: 52-55-9000 2643 lachem@milliken.com

PLEASE NOTE: As each customer's use of our product may be different, information we provide, including without limitation, recommendations, test results, samples, care/labeling/processing instructions or marketing advice, is provided in good faith but without warranty and without accepting any responsibility/liability. Each customer must test and be responsible for its own specific use, further processing, labeling, marketing, etc. All sales are exclusively subject to our standard terms of sale posted at www.milliken.com/terms (all additional/different terms are rejected) unless explicitly agreed otherwise in a signed writing.